


### 1 Installation and Startup Guide

This document covers the installation of cMT2128X Series HMI, for the detailed specifications and operation, please refer to Datasheet, Brochure and EasyBuilder Pro User Manual. Please read all warnings, precautions, and instructions on the device carefully before use.

#### Install Environment:

|   |  |
|---|--|
| NEMA Rating   | The HMI product is NEMA 4 rated (indoor use only).   |
| Electrical Environment  | The HMI product has been tested to conform to European CE requirements. This means that the circuitry is designed to resist the effects of electrical noise. This does not guarantee noise immunity in severe cases. Proper wire routing and grounding will insure proper operation.   |
| Environmental Considerations  | <ol style="list-style-type: none"> <li>(1) Make sure that the displays are installed correctly and that the operating limits are followed. Avoid installing units in environments where severe mechanical vibration or shocks are present.</li> <li>(2) Do not operate the unit in areas subject to explosion hazards due to flammable gases, vapors or dusts.</li> <li>(3) Do not install the unit where acid gas, such as SO<sub>2</sub> exists.</li> <li>(4) This device should be mounted in the vertical position and for use on the flat surface enclosure.</li> <li>(5) For use in Pollution Degree 2 Environment and dry location.</li> <li>(6) Relative Humidity: 10% ~ 90% (non-condensing)</li> </ol> |
| Cleaning Considerations   | Clean the device using dry cloths. Do not use liquid or spray detergents for cleaning.   |
| IP Rating   | IP 66  |
|  Warning | Protection impairment if used in a manner not specified by the manufacturer.<br>Déficit de protection si utilisé d'une manière non spécifiée par le fabricant.   |

### 2 Unpacking the Unit

Unpack and check the delivery. If damage is found, please contact the supplier.

**NOTE: Place the operator panel on a stable surface during installation. Dropping it or letting it fall may cause damage.**


The package includes:

- (1) Installation Instruction, 2-sided A4 \*1
- (2) Human Machine Interface \*1
- (3) Power Connector \*1
- (4) Brackets & Screws \*1 pack
- (5) Fuse 1.6A/250V 5\*20mm \*1

### 3 Installation Instructions

Use a control box that provides enough space for the operator panel in position, using all the provided brackets and screws. (For reaching waterproof preventing the panel from being deformed. Plan for adequate space around the unit enclosure, for ventilation and cables. C from other devices inside the enclosure. temperature around the unit must be 0°C. Minimum required clearances (along the Bottom / Sides 15 mm Maximum panel thickness: 4.5 mm

### 4 Power Connections


 Power Connector Specifications:  
Wire AWG: 24~12  
Wiring Conductor Minimum Temperature: -40°C  
Screw Torque: 4.5 lbf-in (max.)  
Copper conduct only.

#### NOTE:

**1. Connect positive DC line to the '+' terminal and ground to the '-' terminal.**


**2. When downloading project using EasyBuilder Pro, connect HMI with PLC and PC simultaneously. A potential difference may result in damage.**

### 5 System Settings

When HMI is powered up and displays the round Start Button in the upper-left corner of the screen to open the Setting dialog box. Click the  icon and log in. (Default System Password: 111111)

Go to the Network tab, and setup your network. In Setting dialog box you can see device information, configure general settings, set HMI Time, and more.

### 6 EasyBuilder Pro Software

Launch EasyBuilder Pro software, select the Setting dialog box: Select Ethernet > IP tab > click the  file to HMI.

Using screensaver and backlight save settings by displaying the same image on HMI. (Please refer to EasyBuilder Pro User Manual)

## 7 Communication Connections

### NOTE:

1. Only Tx & Rx (no RTS/CTS) may be used for COM1 RS-232 when COM3 RS-232 is also used.
2. COM2 and COM3 RS-485 2W support MPI 187.5K, please use one at a time.

1 2 3 4 5  
6 7 8 9

### Con.B

COM1/COM3 [RS232] 9 Pin, Male, D-sub

| PIN# | COM1<br>[RS232]4W | COM3<br>[RS232]2W |
|------|-------------------|-------------------|
| 1    |                   |                   |
| 2    | RxD               |                   |
| 3    | TxD               |                   |
| 4    |                   |                   |
| 5    | GND               |                   |
| 6    |                   |                   |
| 7    | RTS               | TxD               |
| 8    | CTS               | RxD               |
| 9    | GND               |                   |

5 4 3 2 1  
9 8 7 6

### Con.A

COM2/COM3 [RS485] 9 Pin, Female, D-sub

| PIN# | COM2<br>[RS485]2W | COM2<br>[RS485]4W | COM3<br>[RS485]2W |
|------|-------------------|-------------------|-------------------|
| 1    | Data-             | Rx-               |                   |
| 2    | Data+             | Rx+               |                   |
| 3    |                   | Tx-               |                   |
| 4    |                   | Tx+               |                   |
| 5    | GND (isolation)   |                   |                   |
| 6    |                   |                   | Data-             |
| 7    |                   |                   |                   |
| 8    |                   |                   |                   |
| 9    |                   |                   | Data+             |

## 8 Touchscreen Calibration & Restore Factory Default

### Touchscreen Calibration:

Press and hold anywhere on the screen when HMI starts until it enters touchscreen calibration mode.

### Restore Factory Default:

Follow Step 5 to open the Setting dialog box. Go to "Reset options" tab, press the button of "Reset HMI to default". An Attention window shows, enter "yes".

Another way to restore factory default is entering "default111111" when logging in. An Attention window shows, enter "yes".

Please note that the projects and data stored in the unit are all cleared after pressing this button.

## 9 Battery Replacement

Battery Specification: Type CR2032, Rated 3V

Battery replacement shall be performed by qualified personnel (engineer) only and care must be taken when handling lithium batteries. For more information on battery replacement and disposal considerations, please refer to the following link:

[http://www.weintek.com/download/MT8000/eng/FAQ/FAQ\\_103\\_Replace\\_Battery\\_en.pdf](http://www.weintek.com/download/MT8000/eng/FAQ/FAQ_103_Replace_Battery_en.pdf)


## CAUTION



Power


**NOTE:** Make installing the u

Use power output powered by DC p systems. The pow supply. The peak s




Fusing Require-  
ments

Fuse min. rating: 1 within 5 seconds o of the DC power is Replacing fuse sh <http://www.weintek>




High Voltage

An Internal fuse w voltage sources sh



Emergency Stop

A Hard-wired EME ICS Safety Recom



Supply Voltage  
Condition


Do not power the power supply. Note power the unit.



Wire Routing


- a. Power wire ler
- b. Please use tw impedance ma
- c. If wiring is to b devices.
- d. Keep AC, high
- e. Add a resistor supply and the dissipation. Ty

## DANGER



Hardware  
Considerations

The system desig thereby create an interface can lea physical injury to If you use any pr potential safety ha steps depend on installation of soli installation of Cont



Programming  
Considerations

To conform to ICS ensure that all wr checks built into the personnel.

## Limited Warranty

This product is limited warranted ag The proven defective product will e This warranty shall not cover any p (a) Out of warranty period which is 12 month (b) Damage caused by Force Majeure, acci (c) Product has been repaired or taken apar (d) Products whose identification markings f