

WEINTEK LABS., INC.

# PU PWM Inverter

## iR-PU01-P PWM output; encoder input

Demo Project


## Contents

1. Overview.....	1
2. Installing Weintek Library .....	1
3. Configuring PU Module .....	3
4. Demo Program .....	4
5. Login and Operation.....	5

## 1. Overview

### Overview

This demo project explains how to develop a closed-loop control system using an iR-PU01-P, an inverter and an encoder. In this system, iR-PU01-P's DO-0 is used for PWM output to control the inverter to adjust the speed, and iR-PU01-P receives pulse input from the encoder.




## 2. Installing Weintek Library

**Step 1.** Open the download page on Weintek official website and search for [cMT+CODESYS Package] to download and install the package.

<https://www.weintek.com/globalw/Download/Download.aspx>

(This package contains iR-PU01-P's device description file)

**Step 2.** Add Weintek CODESYS Library in CODESYS software.




**Step 3.** Motion Function Block can be used after completing the installation.

### 3. Configuring PU Module

Parameter	Value	Description
Pulse Input Method	16#16	Set encoder pulse input as a master encoder and the mode is A/B phase (According to encoder specification).
DO 0 Function	16#2	Set DO-0 to PWM output.
PWM Output D0 setting	16#0	Set frequency of PWM output. (Default is 0 and is changeable in the program)
2 <sup>nd</sup> additional position resolution-encoder increments	16#1	Set encoder user units
2 <sup>nd</sup> additional position resolution-motor revolutions	16#1	
2 <sup>nd</sup> additional gear ratio-motor shaft revolutions	16#1	
2 <sup>nd</sup> additional gear ratio-driving shaft revolutions	16#1	
2 <sup>nd</sup> additional feed constant-Feed	16#1	
2 <sup>nd</sup> additional feed constant- driving shaft revolutions	16#1	
2 <sup>nd</sup> additional position modulo range	16#0	Set encoder position modulo range. (Optional)
2 <sup>nd</sup> additional home offset	16#0	Set encoder home offset (Optional)

## 4. Demo Program



Network 1: The motion control function block. When `MC_Power.Status` = `TRUE`, D0 sends PWM output signal.


Network 2: When the frequency of PWM output (`udiFrequency`) is changed, the new frequency is automatically written to iR-PU01-P.

Network 3: Convert PWM output frequency to PWM output parameter for iR-PU01-P's D0.

Network 4: Write / Read PWM output parameter of iR-PU01-P's D0.


## 5. Login and Operation

### Starting Motion Control System



When xEnable & xServo = TRUE, PWM output signal is sent. When encountering an error in this step, please see information about error codes and execute xReset\_Exe to reset.

### Adjusting PWM Output Frequency




udiFrequency\_input can be used to adjust PWM output frequency, and the range is from 20Hz to 100kHz. PWM output frequency immediately changes after the value is input.

When Power\_0.Status = TRUE, iR-PU01-P returns

Axis\_0.Mapping\_I.Obj.AddPositionActual to CODESYS.

## Stopping PWM Output



To stop sending PWM output signal, the user can set udiFrequency\_input to 0.

CODESYS® is a trademark of 3S-Smart Software Solutions GmbH.

Other company names, product names, or trademarks in this document are the trademarks or registered trademarks of their respective companies.

This document is subject to change without prior notice.

Copyright© 2020 Weintek Lab., Inc. All rights reserved.