

WEINTEK IIOT LTD.

# VNC Viewer

Demo Project

**Contents**

1. Overview and Operation ..... 1

2. Object List..... 2


## 1. Overview and Operation

### Overview

This demo project demonstrates how to use the VNC Viewer to display screens from other HMIs or computers.

### Operation

Use the Numeric object to set the VNC server's IP, press [UPDATE], then press [START] to connect.



To connect to another device later, change the IP and press [UPDATE] to refresh the connection.

## 2. Object List

Key objects used in the project are listed below, please adjust as necessary.

Object	Description
Window 10	
VNC Viewer	The control address for VNC Viewer.
Word Lamp	Displays the current VNC Viewer status.
Set Word	Sends commands to VNC Viewer.
Numeric	Sets the IP address of the VNC server.