

# **EasyBuilder Pro** Release Notes

# Software Version : EasyBuilder Pro V6.08.01.296

# **New Features**

#### EasyBuilder Pro

1. [Macro]

Added these functions: CRC16\_CCITT, CRC16\_CCITT\_FALSE, CRC16\_X25, CRC16\_XMODEM, ASCII2DOUBLE, DOUBLE2ASCII

### **Resolved Issues**

- 1. Unicode texts in macro of an older project may turn into gibberish when decompiled.
- 2. System error may occur when a Condition object edited in a certain way is used.
- 3. The server disconnected warning shows when clearing data for the Energy Demand feature.
- 4. In macro functions where device addresses and variables are used, the variables will all be changed to incorrect values following the change of device.
- 5. System error may occur if a cMT Viewer disconnects from the HMI during backup initialized by that cMT Viewer.
- For Action Trigger / Combo Button, Execute JS action containing JavaScript codes that access PLW/PLB data by using GetData / SetData methods may cause subsequent action groups to be skipped.
- **7.** The server disconnected warning shows when the [Support iP/iE/XE/eMT/mTV communication protocol and EasyWatch] option is selected and the port number is set to 8002.

# **Communication and Drivers**

**1.** [Barcode Scanner]

Increased the readable number of characters of QR code.

2. [Siemens S7-200 SMART PPI]

Fixed an issue where the serial port settings are not present when the driver is used on a remote HMI.

- [Mitsubishi iQ-R Series (Ethernet)]
  Fixed an issue where PLC Mode's IQ-R and IQ-F options are erroneously placed in reverse.
- 4. [Panasonic MEWTOCOL7]



# **EasyBuilder Pro** Release Notes v6.08.01

Fixed an issue where tags cannot be imported.

- 5. [Mitsubishi iQ-R Series Binary Mode (Symbolic Addressing) (Ethernet)] Added this driver.
- [YOKOGAWA FA-M3 Binary Mode (Ethernet)] Added this driver.
- [Schneider SoMachine M Series (Ethernet)]
  Fixed communication issues that may occur when array size is too large.
- [OMRON EtherNet/IP (NJ/NX Series)]
  Added support for communication of tags with relatively longer names.
- [Siemens S7-1200/S7-1500 (S7CommPlus, Symbolic Addressing) (Ethernet)]
  Fixed various tag import related issues.
- **10.** *[BACnet Server]* Enhanced support for Device Object's properties.
- 11. [Siemens S7-1200/S7-1500 (Absolute Addressing) (Ethernet)] Allowed the use of dots in address formatting.
- 12. [LS XBM/XBC/XGK CPU DIRECT][LS XGK Cnet][LX XGK FEnet (Ethernet)] Expanded the range of the addresses: MW, MW\_Bit, ZRW, ZRW\_Bit

#### **13.** [Weintek Built-in CODESYS]

Fixed string related issues including data writing issues and macro syntax compatibility issues.



# **EasyBuilder Pro** Release Notes

# Software Version : EasyBuilder Pro V6.08.01.214

### **New Supported Model**

MT8072iP

### **Resolved Issues**

- 1. Find / Replace address replacement issues.
- 2. The available number of channels setting of Trend Display is not properly limited.
- 3. The grid lines of Data Block Display are not correctly displayed.
- 4. Certain Korean fonts cannot be correctly displayed.
- 5. (cMT Series) The maximum number of words of Data Transfer is not properly limited.
- 6. cMT models cannot sample data from non-cMT models.

### **Communication and Drivers**

- 1. [BACnet/MSTP Server] Added support for Property 97.
- [Schneider M340/M580 series]
  Fixed an issue where the arrays that do not start at 0 cannot be read successfully.
- 3. [CO-TRUST CTH300-H (Ethernet)] Expanded V address range.



# EasyBuilder Pro Release Notes

V6.08.01

# Software Version : EasyBuilder Pro V6.08.01.190

# **New Features**

#### EasyBuilder Pro

#### 1. [Address Grid]

Added an option for showing only the addresses in use.

Addres	55	<b>•</b> ×
Mode	Device	
5	Show Addresses in use	
Device name Local HMI		•
Statio	on no. Default	•
Address	s type LB	•
Ad	ddress	
	0 1 2 3 4 5 6 7 8 9	
08990		
09000		
09030		
09040		
12360		

#### 2. [Window Copy]

SQL Query related settings of a source file can be copied.

#### cMT/cMT X Series

Feature additions listed in this section are available for cMT / cMT X series models that support the said features.

1. [Data Transfer (Global)]

Settings can be imported or exported.

#### 2. [Slider]

Non-local HMI device addresses can be used as watch address.

- [Picture]
  A picture object can be enabled or disabled according to the state of a bit address.
- 4. [Event Log]

An event can be enabled or disabled according to the state of a bit address. When an event is disabled, the communication with its related addresses is stopped as well.



# **EasyBuilder Pro** Release Notes V6.08.01

#### 5. [File Browser]

Non-ASCII filenames can be displayed. (OS restrictions apply.)

#### 6. [Data Sampling]

The oldest data can be deleted by using the control command.

#### 7. [Trend Display]

When a watch line is displayed, it will be the center line for zooming along the X axis.

#### 8. [Combo Button]

Added "Change state by ranges" setting for Word Lamp. (Also available for non-cMT models.)

#### 9. [System Settings]

A startup screen can be saved in a project file.

#### **10.** [PLC Web Browser]

Added "Rounded corners" option. (OS restrictions apply.)

**11.** [Trend Display][Event Display] and similar objects whose time range can be specified Optimized the way to set time range.

#### 12. [OPC UA Server]

Added "Information modeling mode".

All features listed in this section are added on cMT / cMT X series for compatibility with the behavior of legacy models.

#### 13. [Trend Display]

Added new option: Value alignment of Y-scale. Available modes include: "Center on tick" and "Full text".

#### cMT Viewer

**1.** Added Droid Sans Japanese font support.

#### Serial Pass-Through

1. Added Mitsubishi A Series Initialization.

# **Communication and Drivers**

 [CODESYS V3 (Ethernet)][Schneider SoMachine M Series (Ethernet)] Added support for string arrays.