

## Software Version : EasyBuilder Pro V6.08.01.350

### *New Supported Models*

cMT3102X (V2), cMT2108X2 (V2)

### *Resolved Issues*

1. Hexadecimal addresses used in macros are not properly displayed in the Find/Replace window and the address list.
2. Display issues of certain fonts.
3. Strings may not be completely displayed in History Data Display (non-cMT only).
4. Some tag selection windows do not appear when using the Find/Replace feature.
5. Some of the settings after compilation are different from those in the original project file.

### *Communication and Drivers*

1. **[KEYENCE KV-8000 (Symbolic) (Ethernet)]**  
Improved connection recovery handling.
2. **[Rockwell DH485]**  
Fixed I/O and File address types related issues including communication issues and data writing issues in data transfer.
3. **[Rockwell EtherNet/IP DF1]**  
Fixed data writing issues in data transfer.
4. **[CODESYS V3 (Ethernet)][Weintek Built-in CODESYS]**  
Fixed an issue where strings cannot be written successfully under certain circumstances.
5. **[Atlas Copco Torque Tool Open Protocol (Ethernet)]**  
Fixed communication issues.
6. **[Inovance Easy Series][Inovance Easy Series (Ethernet)]**  
Added this driver.
7. **[OMRON EtherNet/IP (NJ/NJ Series)]**  
Fixed an issue where the strings in structures or arrays cannot use index registers.
8. **[YASKAWA Sigma-5]**  
Fixed an issue where communication may stop after running for a relatively long period of

time.

9. **[Barcode Scanner/Keyboard]**

Fixed issues related to parameter settings window behaviors.

## Software Version : EasyBuilder Pro V6.08.01.296

### New Features

#### EasyBuilder Pro

##### 1. [Macro]

Added these functions: CRC16\_CCITT, CRC16\_CCITT\_FALSE, CRC16\_X25, CRC16\_XMODEM, ASCII2DOUBLE, DOUBLE2ASCII

### Resolved Issues

1. Unicode texts in macro of an older project may turn into gibberish when decompiled.
2. System error may occur when a Condition object edited in a certain way is used.
3. The server disconnected warning shows when clearing data for the Energy Demand feature.
4. In macro functions where device addresses and variables are used, the variables will all be changed to incorrect values following the change of device.
5. System error may occur if a cMT Viewer disconnects from the HMI during backup initialized by that cMT Viewer.
6. For Action Trigger / Combo Button, Execute JS action containing JavaScript codes that access PLW/PLB data by using GetData / SetData methods may cause subsequent action groups to be skipped.
7. The server disconnected warning shows when the [Support iP/iE/XE/eMT/mTV communication protocol and EasyWatch] option is selected and the port number is set to 8002.

### Communication and Drivers

##### 1. [Barcode Scanner]

Increased the readable number of characters of QR code.

##### 2. [Siemens S7-200 SMART PPI]

Fixed an issue where the serial port settings are not present when the driver is used on a remote HMI.

##### 3. [Mitsubishi iQ-R Series (Ethernet)]

Fixed an issue where PLC Mode's IQ-R and IQ-F options are erroneously placed in reverse.

##### 4. [Panasonic MEWTOCOL7]

Fixed an issue where tags cannot be imported.

**5. [Mitsubishi iQ-R Series – Binary Mode (Symbolic Addressing) (Ethernet)]**

Added this driver.

**6. [YOKOGAWA FA-M3 – Binary Mode (Ethernet)]**

Added this driver.

**7. [Schneider SoMachine M Series (Ethernet)]**

Fixed communication issues that may occur when array size is too large.

**8. [OMRON EtherNet/IP (NJ/NX Series)]**

Added support for communication of tags with relatively longer names.

**9. [Siemens S7-1200/S7-1500 (S7CommPlus, Symbolic Addressing) (Ethernet)]**

Fixed various tag import related issues.

**10. [BACnet Server]**

Enhanced support for Device Object's properties.

**11. [Siemens S7-1200/S7-1500 (Absolute Addressing) (Ethernet)]**

Allowed the use of dots in address formatting.

**12. [LS XBM/XBC/XGK CPU DIRECT][LS XGK Cnet][LS XGK FEnet (Ethernet)]**

Expanded the range of the addresses: MW, MW\_Bit, ZRW, ZRW\_Bit

**13. [Weintek Built-in CODESYS]**

Fixed string related issues including data writing issues and macro syntax compatibility issues.

## Software Version : EasyBuilder Pro V6.08.01.214

### *New Supported Model*

MT8072iP

### *Resolved Issues*

1. Find / Replace address replacement issues.
2. The available number of channels setting of Trend Display is not properly limited.
3. The grid lines of Data Block Display are not correctly displayed.
4. Certain Korean fonts cannot be correctly displayed.
5. (cMT Series) The maximum number of words of Data Transfer is not properly limited.
6. cMT models cannot sample data from non-cMT models.

### *Communication and Drivers*

1. **[BACnet/MSTP Server]**  
Added support for Property 97.
2. **[Schneider M340/M580 series]**  
Fixed an issue where the arrays that do not start at 0 cannot be read successfully.
3. **[CO-TRUST CTH300-H (Ethernet)]**  
Expanded V address range.

## Software Version : EasyBuilder Pro V6.08.01.190

### New Features

#### EasyBuilder Pro

##### 1. [Address Grid]

Added an option for showing only the addresses in use.

	0	1	2	3	4	5	6	7	8	9
08990	■	■	■	■	■	■	■	■	■	■
09000	■	■	■	■	■	■	■	■	■	■
09030	■	■	■	■	■	■	■	■	■	■
09040	■	■	■	■	■	■	■	■	■	■
12360	■	■	■	■	■	■	■	■	■	■

##### 2. [Window Copy]

SQL Query related settings of a source file can be copied.

#### cMT/cMT X Series

Feature additions listed in this section are available for cMT / cMT X series models that support the said features.

##### 1. [Data Transfer (Global)]

Settings can be imported or exported.

##### 2. [Slider]

Non-local HMI device addresses can be used as watch address.

##### 3. [Picture]

A picture object can be enabled or disabled according to the state of a bit address.

##### 4. [Event Log]

An event can be enabled or disabled according to the state of a bit address. When an event is disabled, the communication with its related addresses is stopped as well.

5. **[File Browser]**  
Non-ASCII filenames can be displayed. (OS restrictions apply.)
6. **[Data Sampling]**  
The oldest data can be deleted by using the control command.
7. **[Trend Display]**  
When a watch line is displayed, it will be the center line for zooming along the X axis.
8. **[Combo Button]**  
Added “Change state by ranges” setting for Word Lamp. (Also available for non-cMT models.)
9. **[System Settings]**  
A startup screen can be saved in a project file.
10. **[PLC Web Browser]**  
Added “Rounded corners” option. (OS restrictions apply.)
11. **[Trend Display][Event Display] and similar objects whose time range can be specified**  
Optimized the way to set time range.
12. **[OPC UA Server]**  
Added “Information modeling mode”.

All features listed in this section are added on cMT / cMT X series for compatibility with the behavior of legacy models.

13. **[Trend Display]**  
Added new option: Value alignment of Y-scale. Available modes include: “Center on tick” and “Full text”.

### *cMT Viewer*

1. Added Droid Sans Japanese font support.

### *Serial Pass-Through*

1. Added Mitsubishi A Series Initialization.

## *Communication and Drivers*

1. **[CODESYS V3 (Ethernet)][Schneider SoMachine M Series (Ethernet)]**  
Added support for string arrays.